



RocketMolds, 2.0mL, Clear

Description: This disposable mold & containment system is designed specifically for the compounding pharmacist to efficiently compound vaginal and rectal suppositories in an easily sealable container that is also patient friendly!

Features:

- Easy-to-fill wide opening connected in a string of 10 molds
- Molded from a flexible polymer and UV inhibitor for maximum compatibility
- Transparent for easy visual of contents
- Easy-to-read graduated fill line for accurate filling
- Durable – retains its shape unlike many thin wall options that can be damaged in transit
- One-piece design with an easy-to-seal shut cover: eliminating the need to heat seal
- Designed to individually twist apart for easy counting and dosing
- PVC free
- Recyclable



USA | Canada | Australia | International

medisca.com

Instructions for use:

1. Open cap and insert applicator
2. Flex bottom tab to move dose up
3. Gently squeeze tip to move dose into applicator
4. Remove applicator from RocketMold

USA | CANADA | AUSTRALIA PACIFIC | EUROPE
WWW.MEDISCA.COM

Please note that the information contained herein is for informational purposes only. The information is based on recognized compendia, manufacturers' instructions and/or other authoritative sources and texts. MEDISCA takes no responsibility for the validity or accuracy of this information. Customer MUST refer to USP, FDA, Health Canada, TGA and/or their State Board to ensure they comply with the specific regulations and ensure that appropriate procedures are in place.